



### Custom Fifth Wheel Brackets Kits

- Cuts install time by up to 50%
- Reduces or eliminates drilling
- Provides a custom fit
- To be used in combination with 16104/16204 rails. No need for universal brackets and hardware
- Rail mounting hardware included

Make/Model	Style	Years From	Years To	Bracket Kit#	Notes	Base Rails Needed	
						Carbide	Black
<b>CHEVROLET/GMC</b>							
1500/2500LD Silverado/Sierra	New Body	2007	<b>2016</b>	16414	No Drill	16204	16104
		2007	2014	16412*	No Drill	16204	16104
2500HD/3500 Silverado/Sierra	Classic Body	1999	2007	16418	Drill	16204	16104
		2011	2016	16413	No Drill	16204	16104
		2001	2010	16418	Drill	16204	16104
<b>DODGE/RAM</b>							
Ram 1500	Excluding Air Bag Suspension	2011	2015	16306	Drill	16204	16104
	Excluding Crew Cab	2009	2010	16422	Drill	16204	16104
	Mega Cab	2006	2008	16420	No Drill	16204	16104
	Excluding Mega Cab	2002	2008	16419	No Drill	16204	16104
Ram 2500	Without Factory Prep Package	2014	2016	16427	No Drill	16204	16104
		2013	2013	16426	No Drill	16204	16104
		2003	2012	16420	No Drill	16204	16104
Ram 3500		2013	2016	16426	No Drill	16204	16104
		2003	2012	16420	No Drill	16204	16104
<b>FORD</b>							
F-150	6.5' & 8' Beds	2015	2016	16442	No Drill	16204	16104
		2004	2014	16441	No Drill	16204	16104
		1997	2003	16437	No Drill	16204	16104
F-150 Heritage Edition	Heritage Edition	2004	2004	16437	No Drill	16204	16104
F-250LD	New Body	1997	2003	16437	No Drill	16204	16104
F-250 & F-350 Super Duty		2011	2016	16424	No Drill	16204	16104
		2005	2010	16448	Drill	16204	16104
		1999	2004	16443	Drill	16204	16104
F-450 Super Duty	Excluding Cab & Chassis	2011	2015	16424	No Drill	16204	16104
		2008	2010	16448	Drill	16204	16104
<b>NISSAN</b>							
Titan		2004	2015	16470	Drill	16204	16104
<b>TOYOTA</b>							
Tundra	6' 5" Bed, Excluding Crew Max	2007	2015	16468	Drill	16204	16104
	Standard Cab, Long Box	2000	2006	16465	No Drill	16204	16104

\* Continued while supplies last.

### Semi-Custom Fifth Wheel Bracket Kits

- To be used in combination with 16100/16200 Rails, Hardware, and Brackets for a semi-custom fit
- Drilling required
- \*Except 16300 & 16306. Includes all necessary mounting hardware. Use with 16104 or 16204 rails.

Make/Model	Style	Years From	Years To	Bracket Kit#	Notes	Base Rails Needed	
						Carbide	Black
<b>DODGE</b>							
Ram 1500	Excluding Air Bag Suspension	2009	2015	16306	Drill	16204	16104
		2002	2008	16303	Drill	16200	16100
Ram 2500 & 3500		2003	2012	16301	Drill	16200	16100
<b>FORD</b>							
F-150	Excluding Heritage Edition	2004	2011	16300*	Drill	16204	16104
<b>TOYOTA</b>							
Tundra	6' 5" & 8' Beds, Excluding Crew Max	2007	2008	16304	Drill	16200	16100
	Standard Cab, Long Box	2000	2006	16302	Drill	16200	16100

### Universal Fifth Wheel Base Rails

Part #	Description	Finish
16100	2 Universal Fifth Wheel Base Rails (Includes Rails, Brackets, and Hardware)	Gloss Black
16104	2 Universal Fifth Wheel Base Rails Only (Brackets & Hardware Kit not included)	Gloss Black
16200	2 Universal Fifth Wheel Base Rails (Includes Rails, Brackets, and Hardware)	Carbide Black

Custom and Semi-Custom 5th Wheel Bracket Application Guide

16204	2 Universal Fifth Wheel Base Rails Only (Brackets & Hardware Kit not included)	Carbide Black
16101	Universal Fifth Wheel Rail Mounting Kit. Universal brackets and hardware included	