



Tommy Gate Hitch Chart

There are aftermarket hitches that work with a Tommy Gate, verified Putnam hitches are listed here.

<u>VEHICLE MAKE</u>	<u>YEAR / MODEL</u>	DOES THE FACTORY HITCH WORK WITH A TOMMY GATE?	PUTNAM AFTERMARKET HITCH PART#
Chevy / GMC	*1999-2008 1500 & 2500LD ¹	NO	25148
	*1999-2008 2500HD & 3500HD ¹ (Short Bed)	NO	25181
	*1999-2008 2500HD & 3500HD ¹ (Long Bed)	NO	25188
	2004-2008 Colorado/Canyon	YES	XXXXX
Dodge	2002-2008 1500 Series 2003-2008 2500 & 3500 Series	YES	XXXXX
Ford	1997-2004 F-150 & F-250 LD (old body style)	YES	XXXXX
	2004-2005 F-150	NO	25213
	2006-2008 F-150	NO	25245
	1999-2008 Super Duty Series	YES	XXXXX
Toyota	2000-2006 Tundra(NOT CREW CAB)	NO	25153 ²
	2004-2006 Tundra Crew Cab	NO	25153 ²
	2007-2008 Tundra Fullsize 1/2 Ton	NO	25259

IMPORTANT:

The Putnam hitches specified in this chart will work in conjunction with a Tommy Gate lift. The hitch's rating should not be interpreted as vehicle capability. Please consult with the vehicle manufacturer to find the appropriate gross combination weight rating (GCWR) for your vehicle. GCWR's are based on the truck's engine, transmission, and rear axle ratio. Always travel at a safe speed and use sway control devices when appropriate.

NOTES:

* - In 1999, 2000, and 2007 Chevy / GMC had two body styles for each given year. For a given year the "old" body style is labeled "Classic" and the "new" body style does not have the "Classic" label.

1 - Does not include: 1999-2000 "Classic" pickups.

2 - This hitch may need to be spaced down as much as 1/4" to clear the liftgate.