

## Double Lock QuickGoose2 Application Guide

**Warning:** On two wheel drive trucks a clearance check must be performed when truck is loaded and unloaded to verify the inverted ball will not interfere with the top of the differential.

### 600 Series Installation Kits (Rated to vehicles Max Gross Weight Rating)

Make/Model	Style	Years From	Years To	Double-Lock Hitch#	Quick Goose 2 Hitch#	Under-Bed Folding Ball Gooseneck Hitch #	Rail Kit#	Notes	Double-Lock Hitch/Rail Kit#
<b>CHEVROLET/GMC</b>									
1500 & 2500LD Silverado/Sierra	New Body	2007	2016	60615	n/a	n/a	60632	Z	60711
	Classic Body	1999	2007	60607	60630	61652	60652	Z	60712
2500HD & 3500 Silverado/Sierra		2011	2016	60607	n/a	n/a	60604	Z	60710
		2001	2010	60607	60630	61652	60652	Z,4	60712
2500 & 3500 Full Size Pickups	Old Body Excluding 34" Frame (O.D.)	1999	2000	60607	60630	61652	60631	Z	60713
		1988	1998	60607	60630	61652	60631	Z	60713
<b>DODGE/RAM</b>									
Ram 1500	Air Suspension	2013	2015	60607	n/a	n/a	60658	Z	60731
	Excluding Air Suspension	2009	2015	60607	n/a	n/a	60657	Z	60730
		2002	2008	60607	60640	n/a	60659	Z,1,2	60733
		1994	2001	60607	60640	n/a	60635	Z	60734
Ram 2500		2003	2013	60607	60640	n/a	60661	Z,1,2,6	60732
		2003	2012	60607	60640	n/a	60659	Z,1,2,6	60733
		1994	2002	60607	60640	n/a	60635	Z,6	60734
Ram 3500		2003	2012	60607	60640	n/a	60661	Z,1,2,6	60732
		2003	2012	60607	60640	n/a	60659	Z,1,2,6	60733
		1994	2002	60607	60640	n/a	60635	Z,6	60734
<b>FORD</b>									
F-150		2015	2016	60607	n/a	n/a	60649		n/a
		2004	2014	60607	60630	61652	60641	Z	60721
		1997	2003	60607	60630	61652	60637	Z	60722
		1980	1996	60607	60630	61652	60636	Z,1	60723
		2004	2004	60607	60630	61652	60637	Z	60722
F-250	New Body	1997	2003	60607	60630	61652	60637	Z	60722
	Old Body	1980	1998	60607	60630	61652	60636		60723
F-250 & F-350 Super Duty		2011	2016	60607	60630	61652	60644	Z,3	60720
		1999	2010	60607	60640	n/a	60644	Z,3	60720
		1999	2010	60607	60640	n/a	60643*	Z,3	n/a
F-350	Excluding Overload Springs	1980	1998	60607	60630	61652	60636	Z	60723
		1980	1998	60607	60630	61652	60636		60723
F-450 Super Duty	Excluding Cab & Chassis	2008	2012	60607	60640	n/a	60644	Z,3	60720
		2008	2010	60607	60640	n/a	60643*	Z,3	n/a
<b>NISSAN</b>									
Titan		2004	2015	60620	n/a	n/a	60664	Z,1	60740
<b>TOYOTA</b>									
Tundra	6.5' Bed	2007	2015	60607	n/a	n/a	60667	Z,5	60751
		2000	2006	60625	n/a	n/a	60665	Z,6	60750

\*While Supplies Last

#### 600 Series Footnotes:

- 1 = Passenger side wheel well must be notched for frame rail access
- 2 = Parking brake cable bracket may require relocation
- 3 = Exhaust may have to be permanently lowered on 05 & newer models.
- 4 = Vacuum canister requires relocation (kit included)
- 5 = Ball cannot be turned over, brake lines must be cable tied (ties included)
- 6 = Do not invert ball with heavy loads on 2 wheel drive models
- Z = No frame drilling required

**All Models: Brake, fuel, and electrical lines may need to be loosened or repositioned. Heat shield requires modification or removal**