

CURT MANUFACTURING HITCH APPLICATION GUIDE

| Model | Package | Year | Color | Wheelbase | Drive | Engine | Weight | Capacity | Part # | Part # | Part # | Part # | Part # | Part # | Notes | Notes | Notes | Notes | | | | | | | | | | |
|------------------|--|-------|-------|-----------|-------|--------|--------|----------|--------|--------|--------|--------|--------|--------|---------|-------|-----------|-------|---------------------------------------|--------|-------|-------------------------------------|---------------------------------------|---------------------------------------|--------|-------|-------|---|
| TAHOE | Police Package | 07-14 | | | | | | | | | | | | | 00-15 | 55384 | 5 | ADD | Adds 4-Flat to Factory Equipped 7-Way | 4-Flat | 56187 | 56146 | 2 | | | | | |
| | | 03-06 | | | | | | | 13161 | BB,M,Z | 41 | 6.0 | 15 | | | 56584 | 5 | ADD | Adds 5-Flat to Factory Equipped 7-Way | 5-Flat | 56187 | 56146 | 2 | | | | | |
| | New Body Style (4.8L or 5.3L) | 00-02 | | | | | | | 13402 | Z | 45 | 6/10 | 30 | 14029 | BB,CF,Z | 75 | 16/17 | 30 | 55515 | 5 | REPL | Replaces Factory Connector w 4-Flat | 4-Flat | 56187 | 56146 | 2 | | |
| | Old Body Style (5.7L or 6.5L) | 95-00 | | | | | | | 13605 | M,S,Z | 45 | 5/6 | 30 | 14029 | Z | 67 | 10/12 | 30 | 55515 | 5 | REPL | Replaces Factory Connector w 5-Flat | 5-Flat | 56187 | 56146 | 2 | | |
| TERRAIN | | 10-15 | 12291 | Z | 145 | 3.5 | 30 | 45571 | 45572 | 45521 | 13121 | M,Z | 45 | 3.5/4 | 30 | | | | 10-14 | 56210 | 20 | REPL | | 4-Flat | | 1 | | |
| | | 10-14 | | | | | | | | | 13591 | M,Z | 45 | 3.5/4 | 30 | | | | 10-14 | 56204 | 20 | T | | 4-Flat | | 1 | | |
| TRACKER | | 99-04 | 11024 | Z | 141 | 2.0 | 20 | 45551 | 45552 | 45519 | 13517 | Z | 35 | 3.5/4 | 20 | | | | 98-04 | 55372 | 5 | T | | 5-Flat | 56130 | 56175 | 4 | |
| TRAILBLAZER | Factory Equipped Hitch, Electrical info Only | 02-09 | | | | | | | | | 13029 | M,Z | 41 | 5/6 | 30 | | | | 02-09 | 55384 | 5 | ADD | Adds 4-Flat to Factory Equipped 7-Way | 4-Flat | | 1 | | |
| | | 99-01 | | | | | | | | | 13020 | Z | 41 | 5/6 | 30 | | | | | 99-01 | 55384 | 5 | ADD | Adds 5-Flat to Factory Equipped 7-Way | 5-Flat | | 1 | |
| TRAVERSE | | 09-15 | | | | | | | | | 13300 | M,Z | 45 | 4/6 | 30 | | | | | 09-15 | 55515 | 5 | REPL | Replaces Factory Connector w 5-Flat | 5-Flat | | 1 | |
| | | | | | | | | | | | 13424 | AA,Z | 49 | 5/6 | 30 | | | | | 99-01 | 55411 | 15 | | | | 1 | | |
| | | | | | | | | | | | | | | | | | | | 13-15 | 56245 | 20 | REPL | Factory Replacement 4-Flat w/ Relay | 4-Flat | 56146 | 2 | | |
| | | | | | | | | | | | | | | | | | | | 13-15 | 56181 | 45 | T | | 4-Flat | 56146 | 1 | | |
| | | | | | | | | | | | | | | | | | | | 09-12 | 56022 | 10 | T | | 4-Flat | | 1 | | |
| | | | | | | | | | | | | | | | | | | | 09-15 | 55384 | 5 | ADD | Adds 4-Flat to Factory Equipped 7-Way | 4-Flat | | 1 | | |
| TRAX | | 13-14 | 11358 | M,V | 137 | 2/2.5 | 30 | 45561 | 45562 | 45520 | | | | | | | | | 2013 | 56215 | 5 | REPL | Replaces Factory Connector w 5-Flat | 5-Flat | | 1 | | |
| UPLANDER | 121" Wheelbase Only | 05-09 | 12336 | Z | 147 | 3.5 | 45 | 45571 | 45572 | 45521 | 13336 | Z | 45 | 4/6 | 45 | | | | 2009 | 56216 | 45 | T | Powered | 4-Flat | 56146 | 5 | | |
| VENTURE | | 06-09 | 12244 | | 145 | 3.5 | 30 | 45571 | 45572 | 45016 | 13344 | | 49 | 4/6 | 30 | | | | 05-08 | 56072 | 15 | T | | 4-Flat | | 1 | | |
| VOLVO | | 97-07 | 12244 | | 145 | 3.5 | 30 | 45571 | 45572 | 45016 | 13344 | | 49 | 4/6 | 30 | | | | 97-05 | 55365 | 10 | T | | 4-Flat | 56130 | 56175 | 4 | |
| YUKON & YUKON XL | Factory Equipped Hitch, Electrical info Only | 11-14 | 11221 | AA,V | 125 | 1.0 | 45 | 45571 | 45572 | 45521 | | | | | | | | | 11-12 | 55384 | 5 | ADD | Adds 4-Flat to Factory Equipped 7-Way | 4-Flat | 56187 | 56146 | 2 | |
| | | 07-12 | | | | | | | | | 13422 | M,Z | 47 | 6/10 | 30 | 13324 | BB,CF,Z | 75 | 16/17 | 30 | 55515 | 5 | REPL | Replaces Factory Connector w 4-Flat | 4-Flat | 56187 | 56146 | 2 |
| | New Body Style (Excludes 5.7L) | 00-02 | | | | | | | | | 13422 | M,Z | 47 | 6/10 | 30 | 13524 | BB,CF,S,Z | 67 | 15/16 | 30 | 55515 | 5 | REPL | Replaces Factory Connector w 4-Flat | 4-Flat | 56187 | 56146 | 2 |
| | Old Body Style (5.7L) | 92-00 | | | | | | | | | 13402 | Z | 45 | 6/10 | 30 | 14029 | Z | 67 | 10/12 | 30 | 55515 | 5 | REPL | Replaces Factory Connector w 5-Flat | 5-Flat | 56187 | 56146 | 2 |
| | | | | | | | | | | | 13605 | M,S,Z | 45 | 5/6 | 30 | | | | 92-00 | 55319 | 5 | T | | 4-Flat | | 1 | | |
| | | | | | | | | | | | 13029 | M,Z | 41 | 6/10 | 30 | 14029 | Z | 65 | 10/12 | 30 | 55319 | 5 | T | | 4-Flat | | 1 | |

Trailer hitches in orange cells ship from Eau Claire, Grand Prairie or Mississauga only

| HITCH APPLICATION FOOT NOTES: | | | | | ELECTRICAL SYSTEM NOTES: | | | | |
|-------------------------------------|--|--|---|--|---|--|--|--|--|
| A = Allow additional install time | F = Will not fit vehicles w/ ground effects | N = While supplies last | VT = Vertical receiver tube | | 1 = 2-Wire System - No Converter Needed, 20 Min Install | | | | 9 = System Requires Low-Side Switching Converter, 40 Min Install |
| AA = Main body concealed | G = Add11 install w/ load level air compressor | P = Not w/ roll pan bumper | V = Undercar trimming (not fascia) required | | 2 = 2-Wire System - Use Powered Converter, 40 Min Install | | | | 10 = System Type To Be Determined AT Time of Install |
| B = Relocate or modify exhaust | H = Will not fit vehicles w/ twin tailpipes | Q = Temporary bumper removal | W = Only vehicles w/ boxed steel bumper | | 3 = 2-Wire System - Use HD Powered Converter, 40 Min Install | | | | |
| BB = Main body exposed | I = Will not fit w/ full size spare tire | R = Boxed, bolt-on arms | X = 158" WB remove brace & 118" WB relocate spare | | 4 = 3-Wire System - Use Non-Powered Converter, 20 Min Install | | | | |
| CC = Roll pan modification required | J = Keeps spare tire under vehicle | S = Discontinued | Y = Extra shipping cost as parcel | | 5 = 3-Wire System - Use Powered Converter, 40 Min Install | | | | |
| CF = Canide black finish | K = OEM style hitch | T = Minor modifications required | Z = No drilling required | | 6 = 3-Wire System - Use HD Powered Converter, 40 Min Install | | | | |
| D = Minor fascia trim | L = Fixed draw bar | TG = Compatible w/ Tommy Gate lifts | | | 7 = System Requires PWM-ST Converter, 40 Min Install | | | | |
| E = Noticeable fascia trim | M = Round tube main body | U = May require battery removal for installation | | | 8 = System Requires PWM-STT Converter, 40 Min Install | | | | |
| | | | | | ELECTRICAL ABBREVIATIONS: | | | | |
| | | | | | PWM = Pulse Width Modulation | | | | |
| | | | | | ST = Stop, Tail | | | | |
| | | | | | STT = Stop, Tail, Turn | | | | |