

Indicates change from last listing 9/5/14



RECEIVER HITCHES

1 1/4" - CLASS 1 & 2 RECEIVERS  
 ORDERING OPTIONS (EXAMPLE USING 12094):  
 12094 - HITCH, PIN & CLIP  
 120941 - HITCH WITH 1 7/8" EURO MOUNT, PIN & CLIP  
 120942 - HITCH WITH 2" EURO MOUNT, PIN & CLIP  
 120943 - HITCH OLD-STYLE BALL MOUNT, PIN & CLIP



2" - CLASS 3 RECEIVERS  
 2" HD - CLASSES 4 & 5  
 2" XD - XTRA DUTY  
 (Highlighted in blue)  
 2-1/2" CD - COMMERCIAL DUTY  
 (Highlighted in red)

ELECTRICAL

NO SPLICING REQUIRED  
 ADD = ADDS ADDITIONAL FUNCTION TO FACTORY TOW PACKAGE  
 T = T-CONNECTOR - USE ON VEHICLES w/o FACTORY TOW PACKAGE  
 REPL = REPLACEMENT - USE ON VEHICLES w/ FACTORY TOW PACKAGE

SPLICE-IN CONVERTERS POWERED UPGRADE OPTIONS  
 FROM → TO  
 56130 → 56187  
 56175 → 56146

MAKE & MODEL	STYLE	YEARS	1 1/4"			1 7/8"			2"			2" or 2 1/2"			YEARS	CONNECTOR PART#	INS TIME	TYPE	NOTES	OUTPUT	NON PFCTD PART#	CIRCUIT PART#	WIRE #	ELEC	SYSTEM NOTE
			PART#	FOOT NOTE	PC	WT RTG	INS TIME	PART#	FOOT NOTE	PC	WT RTG	INS TIME	PART#	FOOT NOTE											
SUZUKI AMIGO		98-00												98-00	55360	15	T		4-Flat	56130	56175		4		
		89-94	11247 12181	L,N,Z Z	163 137	2.0 3.5/3	15 15	-- 45571	-- 45572	-- 45521					89-94						56130	56175		4	
AXIOM HOMBRE	w/Under-Vehicle Spare	02-03												02-03							56130	56175		4	
		96-00	12011	Z	145	3.5	45	45551	45552	45519					96-00	55359	5	T		4-Flat				1	
I280, I-350		2006												2006	55510	10	T		4-Flat	56130	56175		4		
		07-08												07-08	55510	10	T		4-Flat	56130	56175		4		
I290, I-370		96-99	11211		161	2.5	40	45551	45552	45503				96-99	55336	10	T		4-Flat	56130	56175		4		
		98-04												98-04	55360	15	T		4-Flat	56130	56175		4		
OASIS RODEO	w/ Under-Vehicle Spare, Excluding 2004 w/ 3.5L engine w/ Door Mounted Spare, Excluding 2004 w/ 3.5L engine	91-97	12021		149	3.5	40	45551	45552	45518				91-97	55331	5	T		4-Flat	56130	56175		4		
		01-03												01-03	55360	15	T		4-Flat	56130	56175		4		
RODEO SPORT	w/ Under-Vehicle Spare, Excluding 2004 w/ 3.5L engine w/ Door Mounted Spare, Excluding 2004 w/ 3.5L engine	01-03												01-03	55336	10	T		4-Flat	56130	56175		4		
		91-93	11595	L,Z	153	1.5	20	--	--	--				91-93						56130	56175		4		
STYLUS TROOPER		92-02	11803	N	153	2.5/2	10	45571	45572	45521				92-02	55339	5	T		4-Flat	56130	56175		4		
		88-91	12181	Z	137	3.5/3	15	45571	45572	45521				88-91						56130	56175		4		
VEHICROSS		99-01												99-01						56130	56175		4		

Trailer hitches in orange cells ship from Eau Claire, Grand Prairie or Mississauga only

HITCH APPLICATION FOOT NOTES:				ELECTRICAL SYSTEM NOTES:			
A = Allow additional install time	F = Will not fit vehicles w/ ground effects	N = While supplies last	VT = Vertical receiver tube	1 = 2-Wire System - No Converter Needed, 20 Min Install	9 = System Requires Low-Side Switching Converter, 40 Min Install		
AA = Main body concealed	G = Add'l install w/ load level air compressor	P = Not w/ roll pan bumper	V = Undercut trimming (not fiscal) required	2 = 2-Wire System - Use Powered Converter, 40 Min Install	10 = System Type To Be Determined At Time of Install		
B = Relocate or modify exhaust	H = Will not fit vehicles w/ twin tailpipes	Q = Temporary bumper removal	W = Only vehicles w/ boxed steel bumper	3 = 2-Wire System - Use HD Powered Converter, 40 Min Install			
BB = Main body exposed	I = Will not fit w/ full size spare tire	R = Boxed, bolt-on arms	X = 158" WB remove brace & 118" WB relocate spare	4 = 3-Wire System - Use Non-Powered Converter, 20 Min Install			
CC = Roll pan modification required	J = Keeps spare tire under vehicle	S = Discontinued	Y = Extra shipping cost as parcel	5 = 3-Wire System - Use Powered Converter, 40 Min Install			
CF = Carbide black finish	K = OEM style hitch	T = Minor modifications required	Z = No drilling required	6 = 3-Wire System - Use HD Powered Converter, 40 Min Install			
D = Minor fascia trim	L = Fixed draw bar	TG = Compatible w/ Tommy Gate lifts		7 = System Requires PWM-ST Converter, 40 Min Install			
E = Noticeable fascia trim	M = Round tube main body	U = May require battery removal for installation		8 = System Requires PWM-STT Converter, 40 Min Install			

ELECTRICAL ABBREVIATIONS:

PWM = Pulse Width Modulation  
 ST = Stop, Tail  
 STT = Stop, Tail, Turn