



Indicates change from last listing 9/5/14

RECEIVER HITCHES

ELECTRICAL

1 1/4" - CLASS 1 & 2 RECEIVERS  
 ORDERING OPTIONS (EXAMPLE USING 12094):  
 12094 - HITCH, PIN & CLIP  
 120941 - HITCH WITH 1 7/8" EURO MOUNT, PIN & CLIP  
 120942 - HITCH WITH 2" EURO MOUNT, PIN & CLIP  
 120943 - HITCH OLD-STYLE BALL MOUNT, PIN & CLIP



2" - CLASS 3 RECEIVERS  
 2" HD - CLASSES 4 & 5  
 2" XD - XTRA DUTY  
 (Highlighted in blue)  
 2-1/2" CD - COMMERCIAL DUTY  
 (Highlighted in red)

NO SPLICING REQUIRED  
 ADD = ADDS ADDITIONAL FUNCTION TO FACTORY TOW PACKAGE  
 T = T-CONNECTOR - USE ON VEHICLES w/o FACTORY TOW PACKAGE  
 REPL = REPLACEMENT - USE ON VEHICLES w/ FACTORY TOW PACKAGE

SPLICE-IN CONVERTERS POWERED UPGRADE OPTIONS  
 FROM-----TO  
 56130 = 56187  
 56175 = 56146

MAKE & MODEL	STYLE	YEARS	1-1/4"			2"			2" or 2 1/2"			YEARS	CONNECTOR PART#	INS TIME	TYPE	NOTES	OUTPUT	NON PFCTD PART#	CIRCUIT PART#	ELEC. SYSTEM NOTE
			1-1/4" PART#	FOOT NOTE	PC	WT RTG	INS TIME	1 7/8" EURO MOUNT PART#	2" EURO MOUNT PART#	OLD-STYLE BALL MOUNT PART#	2" PART#									
<b>PLYMOUTH</b>																				
ACCLAIM		89-95	12025		171	3.5	45	45591	45592	45522										1
BREEZE		96-00	11027		153	2.0	45	45571	45572	45521										4
COLT	2 & 4-Door Sedan	93-94	11767	D	133	2.0	30	45571	45572	45521										4
	Vista and Vista SE Sedan	92-94	11249	Z	167	2.0	15	45571	45572	45521										4
		89-91	11528	D.L	135	1.0	40	--	--	--										
LASER		90-94	11191	D.L	129	1.0	30	--	--	--										1
NEON		00-01	11038		175	2.0	20	45571	45572	45521										1
		95-99	11038		141	2.0	30	45571	45572	45521										
		11-87	11687	LN	115	2.0	30	--	--	--										
VOYAGER & GRAND VOYAGER		96-00	12362	AA	141	3.5	30	45571	45572	45521	13362	AA	49	4/5	30					4-Flat
			12094	BB.Z	133	3.5	30	45571	45572	45521										4-Flat
	FWD	91-95	12141	I.Z	149	3.5	40	45571	45572	45521	13037	I								4-Flat
		84-90	12141	I	149	3.5	40	45571	45572	45521										4-Flat

Trailer hitches in orange cells ship from Eau Claire, Grand Prairie or Mississauga only

HITCH APPLICATION FOOT NOTES:

A = Allow additional install time	F = Will not fit vehicles w/ ground effects	N = While supplies last	VT = Vertical receiver tube
AA = Main body concealed	G = Add'l install w/ load level air compressor	P = Not w/ roll pan bumper	V = Undercar trimming (not fascia) required
B = Relocate or modify exhaust	H = Will not fit vehicles w/ twin tailpipes	Q = Temporary bumper removal	W = Only vehicles w/ boxed steel bumper
BB = Main body exposed	I = Will not fit w/ full size spare tire	R = Bowed, bolt-on arms	X = 15" WB remove brace & 11" WB relocate spare
CC = Roll pan modification required	J = Keeps spare tire under vehicle	S = Discontinued	Y = Extra shipping cost as parcel
CF = Carbide black finish	K = OEM style hitch	T = Minor modifications required	Z = No drilling required
DF = Minor fascia trim	L = Fixed draw bar	TG = Compatible w/ Tommy Gate lifts	
E = Noticeable fascia trim	M = Round tube main body	U = May require battery removal for installation	

ELECTRICAL SYSTEM NOTES:

1 = 2-Wire System - No Converter Needed, 20 Min Install	9 = System Requires Low-Side Switching Converter, 40 Min Install
2 = 2-Wire System - Use Powered Converter, 40 Min Install	10 = System Type To Be Determined At Time of Install
3 = 2-Wire System - Use HD Powered Converter, 40 Min Install	
4 = 3-Wire System - Use Non-Powered Converter, 20 Min Install	
5 = 3-Wire System - Use Powered Converter, 40 Min Install	<b>ELECTRICAL ABBREVIATIONS:</b>
6 = 3-Wire System - Use HD Powered Converter, 40 Min Install	PWM = Pulse Width Modulation
7 = System Requires PWM-ST Converter, 40 Min Install	ST = Stop, Tail
8 = System Requires PWM-STT Converter, 40 Min Install	STT = Stop, Tail, Turn