



Indicates change from last listing 9/5/14

RECEIVER HITCHES

1 1/4" - CLASS 1 & 2 RECEIVERS  
 ORDERING OPTIONS (EXAMPLE USING 12094):  
 12094 - HITCH, PIN & CLIP  
 120941 - HITCH WITH 1 7/8" EURO MOUNT, PIN & CLIP  
 120942 - HITCH WITH 2" EURO MOUNT, PIN & CLIP  
 120943 - HITCH OLD-STYLE BALL MOUNT, PIN & CLIP

2" - CLASS 3 RECEIVERS

2" HD - CLASSES 4 & 5  
 2" XD - XTRA DUTY  
 (Highlighted in blue)  
 2-1/2" CD - COMMERCIAL DUTY  
 (Highlighted in red)

ELECTRICAL

NO SPLICING REQUIRED  
 ADD = ADDS ADDITIONAL FUNCTION TO FACTORY TOW PACKAGE  
 T = T-CONNECTOR - USE ON VEHICLES w/o FACTORY TOW PACKAGE  
 REPL = REPLACEMENT - USE ON VEHICLES w/ FACTORY TOW PACKAGE

SPLICE-IN CONVERTERS POWERED UPGRADE OPTIONS  
 FROM → TO  
 56130 → 56187  
 56175 → 56146

MAKE & MODEL	STYLE	YEARS	1-1/4"			2"			2" HD			YEARS	CONNECTOR PART#	INS TIME	TYPE	NOTES	OUTPUT	NON-FACTORY PART#	CIRCUIT PART#	W/P ELECS	SYSTEM NOTE		
			1-1/4" PART#	FOOT NOTE	PC	WT RTG	INS TIME	1 7/8" EURO MOUNT PART#	2" EURO MOUNT PART#	OLD-STYLE BALL MOUNT PART#	2" PART#											FOOT NOTE	PC
SAAB 900	Convertible	95-98	11730	Q	175	2.0	40	45551	45552	45503													
		86-94	11808	Z	187	2.5/2	30	45571	45572	45521													
		79-80	11622	L.S.Z	145	1.5	45	-	-	-													
	Hatchback	94-98	11730	Q	175	2.0	40	45551	45552	45503													
		87-93	11808	Z	187	2.5/2	30	45571	45572	45521													
		81-86	11807	Z	187	2.5	30	45571	45572	45521													
Sedan	87-93	11808	Z	187	2.5/2	30	45571	45572	45521														
	81-86	11807	Z	187	2.5	30	45571	45572	45521														
	93-98	11811	Z	185	2.5/2	30	45571	45572	45521														
9000	Hatchback	89-92	11810	Z	187	2.5/2	30	45571	45572	45521													
		86-88	11809	D.Z	187	2.5/2	30	45571	45572	45521													
		89-95	11811	Z	185	2.5/2	30	45571	45572	45521													
9-2X	CD or CD Turbo	05-06	11318	Z	129	2.0	30	45571	45572	45022													
		93-98	11811	Z	185	2.5/2	30	45571	45572	45521													
9-3	Convertible, Single Exhaust Convertible, Not recommended for vehicles with "Sport Accessory Rear Air Dam" Hatchback, Not recommended for vehicles with "Sport Accessory Rear Air Dam" Sedan, Single Exhaust Wagon, Single Exhaust Wagon, Dual Exhaust	99-02	11754	D.Z	157	2.0	30	45571	45572	45521													
		99-02	11754	Z	157	2.0	30	45571	45572	45521													
		03-11	11326	D.Z	163	2.0	60	45571	45572	45521													
		06-11	11415	AA.V.Z	129	2.0	60	45571	45572	45521													
		06-11	11140	AA.D.Z	115	2.0	30	45571	45572	45521													
		99-09	11831	BB.Z	163	2.5/2	20	45571	45572	45521													
		99-08	11821	N	169	2.5/2	40	45571	45572	45521													

Trailer hitches in orange cells ship from Eau Claire, Grand Prairie or Mississauga only

HITCH APPLICATION FOOT NOTES:

A = Allow additional install time	F = Will not fit vehicles w/ ground effects	N = While supplies last	VT = Vertical receiver tube
AA = Main body concealed	G = Add'l install w/ load level air compressor	P = Not w/ roll pan bumper	V = Undercar trimming (not fascia) required
B = Relocate or modify exhaust	H = Will not fit vehicles w/ twin tailpipes	Q = Temporary bumper removal	W = Only vehicles w/ boxed steel bumpers
BB = Main body exposed	J = Will not fit w/ full size spare tire	R = Boxed, bolt-on arms	X = 158" W/ remove brace & 118" W/ relocate spare
CC = Roll pan modification required	J = Keeps spare tire under vehicle	S = Discontinued	Y = Extra shipping cost as parcel
CF = Carbide black finish	K = OEM style hitch	T = Minor modifications required	Z = No drilling required
CD = Minor fascia trim	L = Fixed draw bar	TG = Compatible w/ Tommy Gate lbs	
E = Non-replaceable fascia trim	M = Round tube main body	U = May require battery removal for installation	

ELECTRICAL SYSTEM NOTES:

1 = 2-Wire System - No Converter Needed, 20 Min Install	9 = System Requires Low-Side Switching Converter, 40 Min Install
2 = 2-Wire System - Use Powered Converter, 40 Min Install	10 = System Type To Be Determined At Time of Install
3 = 2-Wire System - Use HD Powered Converter, 40 Min Install	
4 = 3-Wire System - Use Non-Powered Converter, 20 Min Install	<b>ELECTRICAL ABBREVIATIONS:</b>
5 = 3-Wire System - Use Powered Converter, 40 Min Install	PWM = Pulse Width Modulation
6 = 3-Wire System - Use HD Powered Converter, 40 Min Install	ST = Stop, Tail
7 = System Requires PWM-ST Converter, 40 Min Install	STT = Stop, Tail, Turn
8 = System Requires PWM-ST Converter, 40 Min Install	