Indicates change from last listing 9/5/14

CURT™ The FIRST Name in Towing Products™

RECEIVER HITCHES

1 1/4" - CLASS 1 & 2 RECEIVERS

ORDERING OPTIONS (EXAMPLE USING 12094):
12094 - HITCH, PIN & CLIP
120941 - HITCH WITH 1 7/8" EURO MOUNT, PIN & CLIP
120942 - HITCH WITH 2" EURO MOUNT, PIN & CLIP
120943 - HITCH OLD-STYLE BALL MOUNT, PIN & CLIP

2" - CLASS 3 RECEIVERS

2" HD - CLASSES 4 & 5

2" XD - XTRA DUTY (Highlighted in blue)
2-1/2" CD - COMMERCIAL DUTY (Highlighted in red)

ELECTRICAL

NO SPLICING REQUIRED

ADD = ADDS ADDITIONAL FUNCTION TO FACTORY TOW PACKAGE
T = T-CONNECTOR - USE ON VEHICLES w/o FACTORY TOW PACKAGE
REPL = REPLACEMENT - USE ON VEHICLES w/ FACTORY TOW PACKAGE

SPLICE-IN CONVERTERS

POWERED UPGRADE OPTIONS
FROM------>TO
56130 = 56187
56175 = 56146

MAKE & MODEL	STYLE	YEARS	1-1/4" PART#	FOOT NOTE	PC	WT RTG	INS TIME	1 7/8" EURO MOUNT PART#	2" EURO MOUNT PART#	OLD-STYLE BALL MOUNT PART#	2" PART#	FOOT NOTE	PC	WT RTG	INS TIME	2" or 2 1/2" PART#	FOOT NOTE	PC	WT RTG	INS TIME	YEARS	CONNECTOR PART#	INS TIME	TYPE	NOTES	OUTPUT	NON PRTCTD PART#	CIRCUIT PRTCTD PART#	ELEC SYSTEM NOTE
VOLVO																													
142		1974	12207		178	3.5/3	45	45571	45572	45521											1974						56130	56175	4
144		1974	12207		178	3.5/3	45	45571	45572	45521											1974						56130	56175	4
145		1974	12207		178	3.5/3	45	45571	45572	45521											1974						56130	56175	4
164		74-75	12207		178	3.5/3	45	45571	45572	45521											74-75						56130	56175	4
240		90-93	12207		178	3.5/3	45	45571	45572	45521											90-93						56130	56175	4
		90-93	11664	D,L	113	1.5	30	--	--	--																			
242	Sedan	75-84	12207		178	3.5/3	45	45571	45572	45521											75-84						56130	56175	4
244		75-89	12207		178	3.5/3	45	45571	45572	45521											74-93						56130	56175	4
		86-89	11664	D,L	113	1.5	30	--	--	--																			
245		75-89	12207		178	3.5/3	45	45571	45572	45521											74-93						56130	56175	4
		86-89	11664	D,L	113	1.5	30	--	--	--																			
264		76-82	12207	E	178	3.5/3	45	45571	45572	45521											76-82						56130	56175	4
265		76-81	12207	E	178	3.5/3	45	45571	45572	45521											76-81						56130	56175	4
740		85-92	12209	D,T,Z	175	3.5/3	40	45571	45572	45521											84-93						56187	56146	5
760		83-90	12209	D,T,Z	175	3.5/3	40	45571	45572	45521											83-96						56187	56146	5
780		88-90	12209	D,T,Z	175	3.5/3	40	45571	45572	45521											88-90						56187	56146	5
850		93-97	12211		137	3.5	30	45571	45572	45521											93-97						56187	56146	5
940		91-95	12209	D,T,Z	175	3.5/3	40	45571	45572	45521											91-95						56187	56146	5
960		95-97	12213	Z	165	3.5/3	30	45571	45572	45521											95-97						56187	56146	5
		92-94	12209	D,T,Z	175	3.5/3	40	45571	45572	45521											91-94						56187	56146	5
C30		11-13	11337	AA,Z	149	2.0	45	45571	45572	45521											11-13							56146	5
	Excluding "R" Models	08-10	11829		149	2.0	45	45571	45572	45521											08-09						56187	56146	5
C70		11-13	11065	AA,Z	141	2.0	20	45591	45592	45522											2011	56119	45	T	Powered	4-Flat	56187	56146	5
	Coupe	98-02	12211		137	3.5	30	45571	45572	45521											98-04						56187	56146	5
S40	4th digit of VIN is "M"	04-11	11438	Z	163	2.0	15	45591	45592	45522											08-10	56069	45	T	Powered	4-Flat	56187	56146	5
	4th digit of VIN is "V"	00-04	11822		147	2.5/2	30	45571	45572	45521											00-07						56187	56146	5
S60		11-15	12066	D,Q,Z	161	3.5	90	45571	45572	45521	13266	D,Q,Z	35	3.5	150						2014	56224	45	T	Powered	4-Flat		56146	5
		01-09	12318	M,Z	141	3.5	30	45571	45572	45016											01-09						56187	56146	5
S70		98-00	12211		137	3.5	30	45571	45572	45521											98-00						56187	56146	5
S80		07-14	12287		125	3.5	60	45561	45562	45520											07-14	56059	45	T	Powered	4-Flat	56187	56146	5
		99-06	12285	D,Z	147	3.5	40	45571	45572	45521											99-06						56187	56146	5
S90		1998	12213	Z	165	3.5/3	30	45571	45572	45521											1998						56187	56146	5
V40		00-04	11822		147	2.5/2	30	45571	45572	45521											00-04						56187	56146	5
V50		05-11	11438	Z	163	2.0	15	45591	45592	45522											05-11						56187	56146	5
V60		2015	12066	D,Q,Z	161	3.5	90	45571	45572	45521	13266	D,Q,Z	35	3.5	150						2015								10
V70		08-10	12066	D,Q,Z	161	3.5	90	45571	45572	45521	13266	D,Q,Z	35	3.5	150						08-10	56060	45	T	Powered	4-Flat	56187	56146	5
		01-07	12318	M,Z	141	3.5	30	45571	45572	45016											98-07						56187	56146	5
		98-00	12211		137	3.5	30	45571	45572	45521																			
V90		1998	12213	Z	165	3.5	30	45571	45572	45521											1998						56187	56146	5
XC60		10-15									13268	AA,V,Z	37	4/4.5	60						2010						56187	56146	5
XC70		08-15	12066	D,Q,Z	161	3.5	90	45571	45572	45521	13266	D,Q,Z	35	3.5	150						08-09	56060	45	T	Powered	4-Flat	56187	56146	5
		03-07	12318	M,Z	141	3.5	30	45571	45572	45016											03-07						56187	56146	5
XC90		03-14									13559	D,Z	49	3.5/5	30						05-14	56045	20	T	Powered	4-Flat	56187	56146	5

Trailer hitches in orange cells ship from Eau Claire, Grand Prairie or Mississauga only

HITCH APPLICATION FOOT NOTES:

A = Allow additional install time	F = Will not fit vehicles w/ ground effects	N = While supplies last	VT = Vertical receiver tube
AA = Main body concealed	G = Add'l install w/ load level air compressor	P = Not w/ roll pan bumper	V = Undercar trimming (not fascia) required
B = Relocate or modify exhaust	H = Will not fit vehicles w/ twin tailpipes	Q = Temporary bumper removal	W = Only vehicles w/ boxed steel bumper
BB = Main body exposed	I = Will not fit w/ full size spare tire	R = Boxed, bolt-on arms	X = 158" WB remove brace & 118" WB relocate spare
CC = Roll pan modification required	J = Keeps spare tire under vehicle	S = Discontinued	Y = Extra shipping cost as parcel
CF = Carbide black finish	K = OEM style hitch	T = Minor modifications required	Z = No drilling required
D = Minor fascia trim	L = Fixed draw bar	TG = Compatible w/ Tommy Gate lifts	
E = Noticeable fascia trim	M = Round tube main body	U = May require battery removal for installation	

ELECTRICAL SYSTEM NOTES:

1 = 2-Wire System - No Converter Needed, 20 Min Install	9 = System Requires Low-Side Switching Converter, 40 Min Install
2 = 2-Wire System - Use Powered Converter, 40 Min Install	10 = System Type To Be Determined At Time of Install
3 = 2-Wire System - Use HD Powered Converter, 40 Min Install	
4 = 3-Wire System - Use Non-Powered Converter, 20 Min Install	**ELECTRICAL ABBREVIATIONS:**
5 = 3-Wire System - Use Powered Converter, 40 Min Install	PWM = Pulse Width Modulation
6 = 3-Wire System - Use HD Powered Converter, 40 Min Install	ST = Stop, Tail
7 = System Requires PWM-ST Converter, 40 Min Install	STT = Stop, Tail, Turn
8 = System Requires PWM-STT Converter, 40 Min Install	