CURT MANUFACTURING HITCH WIRING APPLICATION GUIDE

								REC	EIVER	нітсн	ES					A DUTY NO SPLICING REQUIRED CONVERTIENS IN Diabi ERCIAL DUTY ADD = ADDS ADDDTIONAL FUNCTION TO FACTORY TOW PACKAGE T = T-CONNECTOR - USE ON VEHICLES w/ FACTORY TOW PACKAGE REPL = REPLACEMENT - USE ON VEHICLES w/ FACTORY TOW PACKAGE In red									
The FIRST Name in Towing Products w			1 1/4" - CLASS 1 & 2 RECEIVERS ORDERING OPTIONS (EXAMPLE USING 12094): 12094-1-4TCH (FL, PH & GLUP 12094-1-4TCH WITH 178" EURO MOUNT, PIN & GLIP 120943 - HTCH WITH 2200K MOUNT, PIN & GLIP 120943 - HTCH OLD-STYLE BALL MOUNT, PIN & GLIP					>	2" - CLASS 3 RECEIVER				2" HD - CLASSES 4 & 5 2" XD - XTRA DUTY (Highlighted in blue) 2-1/2" CD - COMMERCIAL DUTY (Highlighted in red)				Y	ADD = ADDS ADDITIONAL FUNCTION TO FACTORY TOW PACKAGE T = T-CONNECTOR - USE ON VEHICLES <u>w/o</u> FACTORY TOW PACKAGE						CONVERTERS POWERED UPGRADE OPTIONS FROM>TO 56130 = 56187	
MAKE & MODEL	STYLE	YEARS	1-1/4" PART#	FOOT NOTE	WT PC RTG 1	1 7/8" EURO NS MOUN IME PART#		OLD- STYLE BALL MOUNT PART#	2" PART#	FOOT NOTE F	PC WTR		2" or 2 1/2" E PART#	FOOT NOTE		WT RTG	INS TIME	YEARS	CONNECTOR PART#	INS TIME TYPE	NOTES	OUTPUT	NON PRTCTD PART#	CIRCUIT PRTCTD PART# ELEC	
FREIGHTLINER	-																					÷	_	L	
SPRINTER	118" WB & 140" WB w/ Single Rear Wheels, 158" WB	03-06							13250 X		59 6/10		14250	х	65	10/12	45	03-06	<u>55381</u>	5 ADD	Adds 4-Flat to Factory Equipped 7-Way	4-Flat		56146	
	140" WB w/ Dual Rear Wheels	03-06							13265		67 6/10														
SPRINTER CAB & CHASSIS	170" WB	07-10							13275		65 6/10	30						07-09						56146	
SPRINTER CARGO VAN 2500	144" WB w/ Step Bumper	07-14							13358 Z		69 5/7.							07-09						56146	
	170" WB w/ Step Bumper	07-14							13358 Z			5 30													
	144" WB w/ Standard Bumper	07-14							13255) 30													
	170" WB w/ Standard Bumper	07-14							13255		69 6/10														
SPRINTER CARGO VAN 3500	144" WB w/ Factory Step Bumper	07-14							13375 B		65 5/7.							07-09						56146	
	170" WB w/ Factory Step Bumper	07-14							13358 Z		69 5/7.													/	
	170" WB w/ Standard Bumper	07-14							13255	6	69 6/10) 30													
																								-	
Trailer hitches in orange cells ship from E	au Claire, Grand Prairie or Mississauga only																								
HITCH APPLICATION FOOT NOTES:												ELEC	CTRICAL SYST	EM NOTES:											
A = Allow additional install time	F = Will not fit vehicles w/ ground effects	N = While s	/hile supplies last				VT = Vertical receiver tube				1 = 2-	1 = 2-Wire System - No Converter Needed, 20 Min Install						9 = System Requires Low-Side Switching Converter, 40 Min Install							
AA = Main body concealed	G = Add'I install w/ load level air compressor	P = Not w/ r	t w/ roll pan bumper				V = Undercar trimming (not fascia) required					2 = 2-	2 = 2-Wire System - Use Powered Converter, 40 Min Install						10 = System Type To Be Determined At Time of Install						
B = Relocate or modify exhaust	H = Will not fit vehicles w/ twin tailpipes	Q = Tempor	Temporary bumper removal				W = Only vehicles w/ boxed steel bumper					3 = 2-	3 = 2-Wire System - Use HD Powered Converter, 40 Min Install												
BB = Main body exposed	I = Will not fit w/ full size spare tire	R = Boxed,	Boxed, bolt-on arms				X = 158" WB remove brace & 118" WB relocate spare				4 = 3-	4 = 3-Wire System - Use Non-Powered Converter, 20 Min Install						ELECTRICAL ABBREVIATIONS:							
CC = Roll pan modification required	J = Keeps spare tire under vehicle	S = Discont	liscontinued				Y = Extra shipping cost as parcel					5 = 3-	5 = 3-Wire System - Use Powered Converter, 40 Min Install						PWM = Pulse Width Modulation						
CF = Carbide black finish	K = OEM style hitch	T = Minor m	= Minor modifications required				Z = No drilling required					6 = 3-	6 = 3-Wire System - Use HD Powered Converter, 40 Min Install						ST = Stop, Tail						
D = Minor fascia trim	L = Fixed draw bar	TG = Comp	atible w/ Tor	nmy Gate lifts	3							7 = Sy	stem Requires P	WM-ST Convert	ter, 40 Min	Install			STT = Stop	, Tail, Turn					
E = Noticeable fascia trim	M = Round tube main body	U = May rec	quire battery	removal for in	stallation							8 = Sv	stem Requires P	WM-STT Conve	erter, 40 Mir	n Install									